




2088 Replacement Kits



| Model Number | 1 Complete Pumphead Assembly | 2 Switch Assembly | 3 Check Valve Assembly | 4 Upper Housing | 5 Bypass/ Non Bypass Valve Assembly | 6 Drive/Impeller Diaphragm Assembly | 7 Motor |
|--------------|---------------------------------|----------------------|---------------------------|--------------------|--|--|------------|
| 2087-593-135 | 94-236-11 | 94-230-36 | 94-237-05 | 94-231-30 | 94-232-05 | 94-238-03 | 11-184-01 |
| 2088-313-145 | 94-236-15 | 94-230-55 | 94-237-05 | 94-231-30 | 94-232-05 | 94-238-03 | 11-185-06 |
| 2088-343-135 | 94-236-11 | 94-230-36 | 94-237-05 | 94-231-30 | 94-232-05 | 94-238-03 | 11-111-00 |
| 2088-343-170 | N/A | N/A | N/A | 94-231-40 | 94-232-05 | 94-238-03 | 11-184-04 |
| 2088-343-500 | N/A | N/A | N/A | 94-231-40 | 94-232-05 | 94-238-03 | 11-111-00 |
| 2088-344-500 | N/A | N/A | N/A | 94-238-00 | 94-232-05 | 94-238-03 | 11-111-00 |
| 2088-394-144 | N/A | N/A | 94-237-05 | 94-231-30 | 94-232-05 | 94-238-03 | 11-195-01 |
| 2088-394-154 | 94-236-11 | 94-230-36 | 94-237-05 | 94-231-30 | 94-232-05 | 94-238-03 | 11-150-10 |
| 2088-414-534 | 94-236-50 | 94-231-10 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 84-008-01 |
| 2088-443-144 | 94-236-20 | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-111-00 |
| 2088-474-144 | 94-236-20 | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-187-00 |
| 2088-483-124 | 94-236-20 | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-179-00 |
| 2088-514-145 | 94-236-14 | N/A | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-185-06 |
| 2088-514-500 | N/A | N/A | N/A | 94-238-00 | 94-232-00 | 94-238-03 | 11-226-07 |
| 2088-554-144 | N/A | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-04 | 11-173-01 |
| 2088-564-144 | 94-236-20 | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-160-10 |
| 2088-573-534 | 94-236-50 | 94-231-10 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 77-004-07 |
| 2088-592-144 | N/A | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-02 | 11-160-00 |
| 2088-594-144 | N/A | N/A | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-195-01 |
| 2088-594-154 | 94-236-21 | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-150-10 |
| 2088-594-154 | 94-236-21 | 94-230-35 | 94-237-00 | 94-231-30 | 94-232-00 | 94-238-03 | 11-150-10 |